




## Terrasoft® Skirting



The perfect wall finish on terraces and balconies can be achieved with the Terrasoft skirting. The 12 cm high element made of pure rubber granules (1-3.5 mm, linear 2-5 mm) is bound with polyurethane and protects walls near the ground from splash water. Even minor scrapes with feet or garden chairs reflect off the soft material, leaving no marks or quirks.


In contrast to conventional solutions made of plaster, wood or steel, the Terrasoft has a much greater thickness (20 mm) and, mounted on the last layer of the floor covering, serves as a retainer - an additional stabilisation of the covering.

### ADVANTAGES

- low maintenance
- easy application
- insulating effect
- protection for walls and inclines

### APPLICATION

Terrasoft skirtings are screwed onto walls or higher steps as a border finish. They serve as an outer finishing for terrace and balcony coverings. For outdoor use.



Glue or screw fixture onto wall footings.

## INSTALLATION INSTRUCTIONS

Terrasoft skirtings can be spot glued on walls of stepped surfaces in accordance with our gluing instructions.

It is also possible to dowel this footing element into place. After fixing the dowel in the wall, holes can be made in the marked positions on the Skirting using a standard wood drill and the plinth screwed in position.

The Skirting should be mounted on the last row of paving slabs and so acts at the same time as a fixture and holding-down element.

### Notes to selective gluing:

Make sure that the adhesive surfaces are free of oil, grease and other residues, e.g. paint, rubber abrasion particles, etc. Now glue the Skirting on the prepared subsoil.

Pierce the membrane in the threaded part of the adhesive cartridge and screw on the cut plastic nozzle. Using a screwdriver, remove the bottom plate of the cartridge and insert it into the manual or pneumatic gun.

The bonding takes place on the completely cleaned underground by means of adhesive dots on the bottom of the Skirting.

The surface and ambient temperature must be at least 5 °C. The Elements should only be glued in dry weather. Adhesive cartridges must not be stored below 10 °C.

Please follow the care instructions.

### Colours



-10x redbrown  
-12x green  
-13x anthracite

### Specifications



### Spert parts



4525001x1  
Gluing

## SURFACE ADHESION

The surface adhesion is mainly for the fixation of solid rubber products.

### Preparation of the subsoil

The concrete foundation must be rough, clean and dry. Please pay attention that the glueing areas are free of oil, greases and other residues e.g. colours, rubber abrasion, cement mist etc.

The surface and environment temperature must be at least 8°C resp. at least 3°C above the dew point temperature. Air temperature not higher than 80%.

### Adhesion priming

Fill adhesion priming in another pot and apply thinly on the subsoil by rolling or painting.

If necessary, subsequently smooth put to avoid puddles.

The drying depends on the air humidity.

With a high air humidity the drying is delayed. In the drying time, a direct water admission should be avoided.


Under certain circumstances, it may be necessary to grind the dried adhesion priming. The grinding dust should be removed thoroughly.

### Glueing process


Admit 1.5 kg hardener to 10 kg glueing and mix it at a low rotative speed achieving a mass free of mist.

When glueing rubber on concrete, the glueing mass should be applied and compressed on the concrete surface with a toothed spatula (4 mm).

Please pay attention that the area is not stepped on for 48 hours.



adhesion priming



glueing process

## JOINT FILLER

The joint filler is applied when already laid elements should be glued together upon the impact edges. This way, it is not possible to take away single elements.

### Processing

With the supplied plastic nozzle, an exact dosage is achieved by simply pressing the middle of the bottle.

Please pay attention that the joint filler remains liquid during the processing period. The joint should not be larger than 3 mm.

Please pay attention that the surface is not stepped on for 48 hours.

## CARE INSTRUCTIONS

A regular care of the layed slabs serves the security and increases its attractive appearance and the life span.

- The dust on Terrasoft areas can be swept off with a broom with hard bristles. The can also be cleaned with a high-pressure cleaner. This also removes dirt residues from the porous surface of the slabs.
- Depending on the degree of soiling, a deep cleaning, e.g. be carried out with a high-pressure cleaner.
- Coloured surfaces can be subsequently refined through application of a special spray coating. In the case of EPDM paving slabs, aggressive soiling due to environmental influences can be removed by sanding down the surface.
- Fouling with moss or grass in the joint area can lead to the panels being pushed apart or pushed up. Be sure to remove such growth early.
- Decolourations of the surface can occur through durable remaining ram moisture on the substrates as well as diverse plants in the direct surroundings of the slabs.
- External influences can have an effect on the condition of the surfaces. Weather, UV radiation, dust from the air, sites near the coast with high salinity or sand areas near the impact protection slabs can have a negative effect on lack of care.
- In cases of abrasion slabs have to be replaced