




## Terrasoft®

# Stabilisation underlay




The solution to prevent the spin dryer from being heard throughout the house is provided by the sound-absorbing Terrasoft Stabilisation Underlay. The  $600 \times 600$  mm format is matched to the dimensions of large electrical appliances and is simply placed underneath the appliance. The Slab consists of pure rubber granulate (1-3.5 mm), bound and coated with polyurethane. A drainage on the underside of the slab allows air to circulate under the electrical appliances, so that no heat accumulation can occur. The stabilisation underlay dampens the operating noise of washing machines, dishwashers and dryers and is a "must have"!

# **ADVANTAGES**

- sound-deadening
- suitable for interiors
- format matched to the dimensions of large electrical appliances
- odourless
- vibration damping
- non-slip

## **APPLICATION**

Wherever there are loud appliance noises, the stabilisation underlay can be used. Under large electrical appliances in kitchens or cellars, bathrooms or utility rooms or, for example, under home trainers and fitness equipment (storage of dumbbells and weights) - the stabilisation underlay is universally deployable!



Simply lay down: with the Terrasoft Stabilisation Underlay you quickly and safely have a non-slip, sound-absorbing base.

# **INSTALLATION INSTRUCTIONS**

The Terrasoft Stabilisation Underlay is simply placed as a sound-insulator under large electrical appliances. Moreover, it can be used as a non-slip stabilisation, for example, for ladders.

Please follow the care instructions.



Terrasoft Stabilisation underlay redbrown



Terrasoft Stabilisation underlay green



Terrasoft Stabilisation underlay anthracite

#### Colours



-10x

redbrown







-12x -13x green anthracite



Specifications









## **SURFACE ADHESION**

The surface adhesion is mainly for the fixation of solid rubber products.

#### Preparation of the subsoil

The concrete foundation must be rough, clean and dry. Please pay attention that the glueing areas are free of oil, greases and other residues e.g. colours, rubber abrasion, cement mist etc.

The surface and environment temperature must be at least 8 °C resp. at least 3 °C above the dew point temperature. Air temperature not higher than 80%.

#### Adhesion priming

Fill adhesion priming in another pot and apply thinly on the subsoil by rolling or painting.

If necessary, subsequently smooth put to avoid puddles. The drying depends on the air humidity.

With a high air humidity the drying is delayed. In the drying

time, a direct water admission should be avoided. Under certain circumstances, it may be necessary to grind

the dried adhesion priming. The grinding dust should be removed thoroughly.

#### Glueing process


Admit 1.5 kg hardener to 10 kg glueing and mix it at a low rotative speed achieving a mass free of mist.

When glueing rubber on concrete, the glueing mass should be applied and compressed on the concrete surface with a toothed spatula (4 mm).

Please pay attention that the area is not stepped on for 48 hours.







# **JOINT FILLER**

The joint filler is applied when already laid elements should be glued together upon the impact edges. This way, it is not possible to take away single elements.

#### **Processing**

With the supplied plastic nozzle, an exact dosage is achieved by simply pressing the middle of the bottle.

Please pay attention that the joint filler remains liquid during the processing period. The joint should not be larger than 3 mm

Please pay attention that the surface is not stepped on for 48 hours.

## **CARE INSTRUCTIONS**

A regular care of the layed slabs serves the security and increases its attractive appearance and the life span.

- The dust on Terrasoft areas can be swept off with a broom with hard bristles.
- Coloured surfaces can be subsequently refined through application of a special spray coating.
- Fouling with moss or grass in the joint area can lead to the panels being pushed apart or pushed up. Be sure to remove such growth early.
- Decolorations of the surface can occur through durable remaining ram moisture on the substrates as well as diverse plants in the direct surroundings of the slabs.
- External influences can have an effect on the condition of the surfaces. Weather, UV radiation, dust from the air, sites near the coast with high salinity or sand areas near the impact protection slabs can have a negative effect on lack of care.
- In cases of abrasion slabs have to be replaced